




80L QFN DAISY CHAIN TOP VIEW



| DAISY CHAIN NET LIST | | |
|-------------------------|---------|---------|
| PINS | PINS | PINS |
| 1 ~ 2 | 3 ~ 4 | 5 ~ 6 |
| 7 ~ 8 | 9 ~ 10 | 11 ~ 12 |
| 13 ~ 14 | 15 ~ 16 | 17 ~ 18 |
| 19 ~ 20 | 21 ~ 22 | 23 ~ 24 |
| 25 ~ 26 | 27 ~ 28 | 29 ~ 30 |
| 31 ~ 32 | 33 ~ 34 | 35 ~ 36 |
| 37 ~ 38 | 39 ~ 40 | 41 ~ 42 |
| 43 ~ 44 | 45 ~ 46 | 47 ~ 48 |
| 49 ~ 50 | 51 ~ 52 | 53 ~ 54 |
| 55 ~ 56 | 57 ~ 58 | 59 ~ 60 |
| 61 ~ 62 | 63 ~ 64 | 65 ~ 66 |
| 67 ~ 68 | 69 ~ 70 | 71 ~ 72 |
| 73 ~ 74 | 75 ~ 76 | 77 ~ 78 |
| 79 ~ 80 | | |



RECOMMENDED
PCB PADS



AFTER MOUNTING
ON PCB

NOTES:

1. DAISY CHAIN WIRE BONDED TO INTERNAL PADS.
2. SEE NET LIST FOR CONNECTIONS BETWEEN PINS.
3. DRAWING NOT TO SCALE.

| | | | |
|--|-----------|-----------------------|--------------|
| TopLine® | | | |
| TITLE 80L QFN - DAISY CHAIN PIN CONNECTIONS | | | |
| SCALE | SIZE A | DRAWING NO. 128017 | REV A |
| DO NOT SCALE DRAWING | | | SHEET 1 OF 1 |